

ADFI Free Trial Tutorial

August 2022 edition

AI Robotics Ltd.



In this tutorial, you will create an image anomaly detection AI using a sample image dataset and verify the performance of the AI. The procedure is explained in the following flow.

- 1. Create an account (first time login only)
- 2. Preparing the dataset
- 3. Creation of an image anomaly detection AI
- 4. Performance verification of the AI
- 5. Supplementary information





- Access the official website of ADFI (<u>https://adfi.jp/</u>).
- Click "Sign In/Sign Up" on the upper right. Go to ADFI app.





- This is the top page of the ADFI app (<u>https://web.us.adfi.karakurai.com/webapp/</u>).
- Please click "Create a new account" for the first time.
 - From the second time onwards (after creating an account), please press the "SIGN IN" button.

ADFI									
Welcome to ADFI!									
	If you don't have your account, please create a new account.								
	SIGN IN Create a new account								
	If you find a bug or have a request for improvement, please send us your feedback from the menu on the top right.								



- Create a new account. Enter the account information to be registered (user name, email address, password, password confirmation).
- After checking the check box at the bottom left, press the "REGISTRATION" button. A confirmation email will be sent to the email address you entered.





- You will receive a confirmation email from ADFI (info-web@airobotics.jp) titled "ADFI Please Confirm Your E-mail Address", so please click the URL in the email.
- By clicking the URL, you can log in with the email address and password you entered earlier.
 - If you do not receive the e-mail, it may have been sorted into your spam box or the e-mail address you entered may be incorrect.
- Click "Sign in".

You are receiving this e-mail because a new user has given your e-mail address to register an account on ADFI. To confirm this is correct, go to	ADFI
https://us.adfi.karakurai.com/ap/auth/registration/account-confirm-email/?id-	Your email address has been verified!
You can find ADFI operation manual at the following URL. https://adfi.jp/manual/ Thank you for using ADFI!	



- Log in to the ADFI app. Enter the account information (email address and password) you registered earlier.
- You can login to the ADFI app by pressing the "SIGN IN" button.

email 0/128
email 20/128
Password Or
SIGN IN
Create a new account Forgot your password?
If you find a bug or have a request for improvement, please send us your feedback from the menu on the top right.





- Prepare the datasets necessary for creating an image anomaly detection AI and verifying its performance. After logging in to the ADFI app, press "Sample Dataset" on the left menu.
 - If the menu is not displayed, press the icon on the upper left.



- The download page of the ADFI official site is displayed. Click "Coffee beans (22.7MB)" in the middle of the page to download a sample image data set (examination of foreign matter in coffee beans).
 - An image containing only coffee beans is a normal image, and an image containing a foreign object (chocolate or candy) is an anomalous image.
- Expand the downloaded compressed file "Coffee_beans.zip".





If you use the dataset in scientific work or web site, please cke: ADR, "Real World Dataset for Anomaly Detection", Al Robotics CTD., 2022, hepA ADFI



- First, create a project. Go back to the ADFI app and click "Project" on the left menu.
- Please press the "NEW PROJECT" button on the upper right.

=	ADFI				номе	YOURUSERNAME -
۲	Project	Projects				+ NEW PROJECT
	Billing	Name	ID	Created \downarrow	Actions	
ø	API		N Create a new project by	o project data clicking the button on the top right.		
₽	Sample Dataset				Rows per page: 10	• - < >
0	Operation Manual					
Copyri	ght © 2022 AI ROBOTICS L	TD. All rights reserved.				-



• Enter the project name you want to create and click "SAVE".

≡	ADFI				номе	YOURUSERNAME -
	Project	Projects				+ NEW PROJECT
	Billing	Name	ID	Created \downarrow	Actions	
۵	API		Creat	No project data e a new project by clicking the button on the top right	t	
•	Sample Dataset				Rows per page: 10	• - < >
v	operator i malitua		New Project	CANCEL SAVE		
Copyri	ight © 2022 AI ROBOTICS L	TD. All rights reserved.				



• A new project has been created. Please click the created project name. The project detail is displayed.

≡	ADFI			номе	YOURUSERNAME -
Ŷ	Project	Projects			+ NEW PROJECT
	Billing	Name	ID	Created \downarrow	Actions
ø	API	Sample Project	a03a6a3a-438f-44ce-becf-80328c3e9e70	Aug 16, 2022 at 2:56 PM	× =
+	Sample Dataset			Rows per page: 10 👻	1-1 of 1 < >
0	Operation Manual				
Copyri	ight © 2022 AI ROBOTICS L	TD. All rights reserved.			



- Project details allow you to add project members or create datasets.
- Press the "NEW DML DATASET" button on the right.
 - This time, you will use the "DML" algorithm for the AI algorithm. If you want to use the "PCA" algorithm, press the "NEW PCA DATSET" button on the bottom right.

=	ADFI					нс	DME YOURUSERNAME -						
•	Project Billing	<< Back to Project List Page Project Detail											
۵	API	Project Name		Sample Project									
₽	Sample Dataset	Project ID		a03a6a3a-438f-44ce-becf-	80328c3e9e70								
0	Operation Manual	Owner Name		YourUserName									
		Project Members					🕰 ADD MEMBER						
		Name	ID				Actions						
		YourUserName	YourUserName 738fd918-1705-412d-b1c9-e6cce213fa5c										
						Rows per page: 10	▼ 1-1 of 1 < >						
		Dataset for DML					+ NEW DML DATASET						
		Img Name	ID	Status	Plan	Created \downarrow	Actions						
		No Dataset data Create a new DML Dataset by clicking the button on the top right.											
						Rows per page:	10 💌 - < >						
Copyri	ght © 2022 AI ROBOTICS L	TD. All rights reserved.											



• Enter the dataset name you want to create and click "SAVE".





• A new dataset has been created. Click the created dataset name. Dataset detail is displayed.

≡	ADFI		номе	YOURUSERNAME -
۲	Project	<< Back to Project List Page Project Detail		
	Billing	····;····		
ø	API	Project Name Sample Project		
1	Sample Dataset	Project ID a03a6a3a-438f-44ce-becf-80328c3e9e70		
0	Operation Manual	Owner Name YourUserName		
		Project Members		+ ADD MEMBER
		Name ID		Actions
		YourUserName 738fd918-1705-412d-b1c9-e6cce213fa5c		
		Rows per page	£: 10 ▼	1-1 of 1 < >
		Dataset for DML	+	NEW DML DATASET
		Img Name ID Status Plan	Created 🗸	Actions
		Sample Dataset ee0f3b37-4878-44b6-b059-227988043873 Available Free	Aug 16, 2022 at 3	:12 PM 🕜 🗑
Соруг	ight © 2022 AI ROBOTICS L	Rows per page TD. All rights reserved.	e: 10 ▼	1-1 of 1 < >



- In the dataset detail, you can register images for AI learning and performance verification, and create an AI and verify its performance.
- First, register normal images for learning. Press the "Normal Training image" button.

AD	FI						ном
	Project	<< Back to Project Detail Page					
	Billing	Dataset Detail					
	API	Dataset Name		Sample Dataset			
5	Sample Dataset	Dataset ID		ee0f3b37-4878-44b6-b059-	227988043873		
	Operation Manual	Owner Name		YourUserName			
		Sample Image		NO IMAGE			
		Plan		Free (Remaining 14 days)			
		Payer ⑦					
		API Call Status		Not available (Free API avai	ilable: 100) 🏟 🔒		
		Training Data (At least 20 normal data and 5 anomalous e	data)	Total: 0 Normal: 0, Anomaly: 0			
		Test Data (At least 1 data)		Total: 0 Normal: 0, Anomaly: 0			
		Al Model Status		No Al model exists			
		AI MO	DEL INSPECTION RANGE SETT	ING AI MODEL SETTING	TEST AP	1	
		Normal Training image	🗅 Anomalous Training image	Normal Test image	▲ Anomalous Test	timage 📱 Dele	te ALL Data
		Image List		dp Create Al Model		l 👘 Re-training	dp Test
		Img ID Name	Created ↓ ForTraining	ForTest	Label	cellSelected	Actions
			N	o data available			
					Rows per pag	ge: 10 + -	$\langle \rangle$



- Open the good folder (Coffee_beans -> train -> good) in the train folder of the sample image dataset that you expanded earlier.
- Select all the images in the good folder and press the "Open" button.
 - In Windows, you can select all at once with the "Ctrl" button + "A" button.





- After completing the upload of the image you selected earlier, a list of registered images will be displayed at the bottom of the dataset detail screen.
- Please press the icon on the left of any image information. You can check the registered image.

=	ADFI									HOME
		(At leas	t 1 data)		Normal: 0, Ar	iomaly: 0				
6	Project	Al Mode	el Status		No Al model	exists				
Ξ	Billing		AI MODEL	INSPECTION RANG	E SETTING AI MODEL	SETTING	TEST	API		
e	API		A Normal Training image	nomalous Training	image 🛆 Normal Te	st image	Anomalous	Test image	Delete Al	LL Data
6	Sample Dataset	Image	e List		🖶 Create	Al Model	📋 Delete Al M	odel 🖶 R	e-training d	🖶 Test
6	Operation Manual	Img	ID	Name	Created \downarrow	ForTraining	ForTest	Label	cellSelected	Actions
			4ad32158-9b57-4b91-ab24-b2760bb2c51	2 good_050.jpg	Aug 16, 2022 at 3:36 PM	Y		NORMAL		Z 1
		B	48962143-9011-4d36-832b-3b4d9d6473a8	good_049.jpg	Aug 16, 2022 at 3:36 PM	Y		NORMAL		× 1
		•	03d7b2ed-8864-4b89-acca-52c2ce1b2397	good_048.jpg	Aug 16, 2022 at 3:36 PM	V		NORMAL		Z 1
		B	5d91eec6-9640-4302-8627-f01dfc308387	good_047.jpg	Aug 16, 2022 at 3:36 PM	V		NORMAL		Z II.
		B	5773f5be-fdb8-46a9-91c2-f5d5c0f3d172	good_046.jpg	Aug 16, 2022 at 3:36 PM	2		NORMAL		1
		•	50e1b145-39a9-41c8-91cd-80b1bca24a8	good_045.jpg	Aug 16, 2022 at 3:36 PM	V		NORMAL		/=
		8	3cec602c-d0de-44f8-b3cb-2bfa53e1c7a4	good_044.jpg	Aug 16, 2022 at 3:36 PM			NORMAL		Z 1
		8	5e40ec4b-06f1-494d-85ac-350f01075583	good_043.jpg	Aug 16, 2022 at 3:36 PM			NORMAL		/ 1
		8	b7de7df1-d196-4444-91f3-a73f3918fb0c	good_042.jpg	Aug 16, 2022 at 3:36 PM	V		NORMAL		/ 1
		8	0cf229da-2854-424a-8b12-e107af462a9c	good_041.jpg	Aug 16, 2022 at 3:36 PM	2		NORMAL		Z I
							Rows per page:	10 👻	1-10 of 50	< >



• The registered image is displayed. Please click "CLOSE" in the lower right.

=	ADFI										YOURUSERNAME
_		(At least	1 data)		Normal: 0, An	iomaly: 0					
	Project	Al Model	Status	atus No Al model exists							
	Billing		AI MODEL IN	SPECTION RANG	E SETTING AI MODEL	SETTING	TEST	API			
0	API		A Normal Training image And	malous Training	image 🙆 Normal Te	st image	Anomalous 1	Test image	Delete AL	LData	
۵	Sample Dataset	Image	List		🚓 Grente /		B Delate Al Mo			Test	
0	Operation Manual	Imp	10	Name	Created 🕁	ForTraining	ForTest	Label	cellSelected	Actions	
		8	4ad32158-9b57-4b91-ab24-b2760bb2c512	good_050.jpg	Aug 16, 2022 at 3:36 PM			NORMAL	•	× 1	
			48962143-9011-4036-8320-364-4046-499-6	2020	* 16, 2022 at 3:36 PM			NORMAL		× 1	
		83	03d7b2ed-8864-4b89-sccs-52		16, 2022 at 3:36 PM			NORMAL	8	× 1	
		2	5d91eec6-9640-4302-8627-f0		16, 2022 at 3:36 PM			NORMAL	8	× 1	
		8	5773f5be-fdb8-46a9-91c2-f5d	3	16, 2022 at 3:36 PM			NORMAL	•	× 1	
		8	50e1b145-39a9-41c8-91cd-80b1bca24a8c	good_045.jpg	× CLOSE Aug 6.2022313.31 PM			NORMAL		× 1	
		2	3cec602c-d0de-44f8-b3cb-2bfa53e1c7a4	good_044.jpg	Aug 16, 2022 at 3:36 PM			NORMAL		× 1	
		8	5e40ec4b-06f1-494d-85ac-350f01075583	good_043.jpg	Aug 16, 2022 at 3:36 PM	2		NORMAL		× 1	
		8	b7de7df1-d196-4444-91f3-e73f3916fb0c	good_042.jpg	Aug 16, 2022 at 3:36 PM	23		NORMAL	•	~ =	
		23	0cf229da-2854-424a-8b12-e107af462a9c	good_041 jpg	Aug 16, 2022 at 3:36 PM			NORMAL	8	× 1	
							Rows per page:	10 -	1-10 of 50	•	
Соругі	ght © 2022 AI ROBOTICS LTD. All rights reserved.										



- Next, register anomalous images for learning. Press the "Anomalous Training image" button.
 - This operation is only required for the "DML" algorithm. In the case of the "PCA" algorithm, registration of anomalous images for training is not required.

=	ADFI										HOME	YOURUSERNAME -
			(At least	1 data)		Normal: 0, An	omaly: 0					
	Project		Al Model	Status		No Al model e	exists					
	Billing			AI MODEL INS	SPECTION RANG	E SETTING AI MODEL	SETTING	TEST	API			
0	API			A Normal Training image	malous Training	image 🙆 Normal Tes	st image	Anomalous 1	Test image	Delete ALI	Data	
ŀ	Sample Dataset		Image	List	•	🖶 Create /	Al Model	📋 Delete Al Mo	odel 🖶 R	e-training 🖷	Test	
0	Operation Manual		Img	ID	Name	Created \downarrow	ForTraining	ForTest	Label	cellSelected	Actions	
			-	4ad32158-9b57-4b91-ab24-b2760bb2c512	good_050.jpg	Aug 16, 2022 at 3:36 PM			NORMAL		Z 1	
				48962143-9011-4d36-832b-3b4d9d6473a8	good_049.jpg	Aug 16, 2022 at 3:36 PM			NORMAL		/ =	
				03d7b2ed-8864-4b89-acca-52c2ce1b2397	good_048.jpg	Aug 16, 2022 at 3:36 PM			NORMAL		× 1	
				5d91eec6-9640-4302-8627-f01dfc308387	good_047.jpg	Aug 16, 2022 at 3:36 PM			NORMAL		× 1	
			-	5773f5be-fdb8-46a9-91c2-f5d5c0f3d172	good_046.jpg	Aug 16, 2022 at 3:36 PM			NORMAL		/ =	
				50e1b145-39a9-41c8-91cd-80b1bca24a8c	good_045.jpg	Aug 16, 2022 at 3:36 PM			NORMAL		/ =	
				3cec602c-d0de-44f8-b3cb-2bfa53e1c7a4	good_044.jpg	Aug 16, 2022 at 3:36 PM			NORMAL		Z II.	
				5e40ec4b-06f1-494d-85ac-350f01075583	good_043.jpg	Aug 16, 2022 at 3:36 PM			NORMAL		/ 1	
				b7de7df1-d196-4444-91f3-a73f3918fb0c	good_042.jpg	Aug 16, 2022 at 3:36 PM			NORMAL		/ =	
				0cf229da-2854-424a-8b12-e107af462a9c	good_041.jpg	Aug 16, 2022 at 3:36 PM			NORMAL		Z II.	
								Rows per page:	10 -	1-10 of 50	~ >	
Сору	ight © 2022 AI ROBOTICS L	TD. All rights reserved.										

- **ADFI**
- Open the chocolate folder (Coffee_beans -> train -> chocolate) in the train folder of the sample image dataset.
- Select all the images in the chocolate folder and press the "Open" button.
 - In Windows, you can select all at once with the "Ctrl" button + "A" button.





- After completing the upload of the anomaly image, the anomaly image is added to the image list.
- Anomaly images for training should specify anomalous regions in the image. Press the "Select" button to the right of the image information.
 - Anomaly images that do not specify an anomaly region are not used for AI training.

AUFI										HOME
Proje Billin API	ect 19	Sam	Jie image	*						
Samp	ple Dataset	Plan		Free (Remaining 14 days	:)					
Open	ration Manual	Paye	0							
		API (all Status	Not available (Free API a	wailable: 100) 🔹 🔒					
		Train (At le data	ng Data ast 20 normal data and 5 anomalous	Total: 50 Normal: 50, Anomaly: 0 Notice: There are 10 and image.	malous data with no anoma	alous cell selecte	d. Please click t	he select button of	each anomalous	training
		Test (At le	Data ast 1 data)	Total: 0 Normal: 0, Anomaly: 0						
		AI M	Al Model Status No Al model exists							
			AI MODE	L INSPECTION RANG	E SETTING AI MODE	L SETTING	TEST	API		
			A Normal Training image	▲ Anomalous Training	image 🙆 Normal T	est image	🛆 Anomalou	s Test image	Delete AL	L Data
		Ima	ige List		de Create	Al Model	🗑 Delete Al	Model 👘 Re	-training 🏟	Test
						Res Technics				0.0000000
		Img	ID	Name	Created ψ	rorisaining	ForTest	Label	cellSelected	Actions
		Img	iD b470799e-ebc3-475f-b0f5- 282a7ff0cd3e	Name chocolate_010.jpg	Created ↓ Aug 17, 2022 at 10:53 AM	. Por Insening	ForTest	Label	Select	Actions
			10 b470798e-ebc3-475f-b0f5- 282a7ff0cd3e a719a5af-a5c7-4d76-ac1f- fcc15ef877ee	Name chocolate_010.jpg chocolate_009.jpg	Created J Aug 17, 2022 at 10:53 AM Aug 17, 2022 at 10:53 AM		ForTest	Label ANOMALY ANOMALY	cellSelected Select Select	Actions
		1100 	10 b470798eebc3-475f-b0f5- 282a7ff0cd3e a719858f-85C7-4d76-ac1f- foc15ef877ee eed53b17-4a96-407e-b166- 2af5c3444d37	Name chocolate_010.jpg chocolate_009.jpg chocolate_008.jpg	Created J Aug 17, 2022 at 10:53 AM Aug 17, 2022 at 10:53 AM Aug 17, 2022 at 10:53 AM		ForTest	Label ANOMALY ANOMALY ANOMALY	cellselected Select Select Select	Actions
			ID b470798eebc3-475f-b0f5- 282a7ff0cd3e a719858f-85C7-4d76-ac1f- foc15ef877ee eed53b17-4a96-407e-b166- 2af5c3444d37 10282a8e-ac0f-47c8-9c60- Deadadab066f	Name chocolate_010.jpg chocolate_009.jpg chocolate_008.jpg chocolate_007.jpg	Created-J Aug 17,2022 at 10:53 Aug 17,2022 at 10:53			Label ANOMALY ANOMALY ANOMALY ANOMALY	cellSelect Select Select Select Select	Actions Act



- Specifies the abnormal region in the image. From the 16 divisions of the image, select and click on one area that contains an anomaly. Selected areas are displayed in green.
 - If the anomaly exists in multiple areas, select the one that is the most characteristic.
- After selecting, press the "SAVE" button on the upper left.





- A check mark is displayed to the right of the image information that selected the anomaly area.
- Repeat the same operation for each image information, and change all "Select" buttons to display check marks.

ADFI								номе
Project Billing API	Sample Image							
Sample Dataset	Plan	Free (Remaining 14 days)					
Operation Manual	Payer ②							
	API Call Status	Not available (Free API a	vailable: 100) 🏟 🔒					
	Training Data (At least 20 normal data data)	and 5 anomalous Motioe: There are 9 anom image.	alous data with no anomalou	is cell selected.	Please click the si	elect button of e	ach anomaíous :	raining
	Test Data (At least 1 data)	Total: 0 Normal: 0, Anomaly: 0						
	Al Model Status	No Al model exists						
		AI MODEL INSPECTION RANGE	SETTING AI MODEL	SETTING	TEST	API		
	A Normal	Training image 🛛 Anomalous Training	image 🛆 Normal Tes	t image 🛛 🗖	Anomalous T	est image	Delete AL	L Data
	Image List		dy Creste A	i Model 🛙	Delete Al Mo	del 🌵 Re	-training न	r Test
	1mg ID	Name	Created \downarrow	ForTraining	ForTest	Label	cellSelected	Actions
	b470798e-ebc 282a7ff0cd3e	:3-475f-b0f5- chocolate_010.jpg	Aug 17, 2022 at 10:53 AM			ANOMALY	0	2.8
	a719a5af-a5c fcc15ef877ee	7-4d76-ac1f- chocolate_009.jpg	Aug 17, 2022 at 10:53 AM			ANOMALY	Select	× =
	eed53b17-4a9 2af5c3d44d3	16-407e-b166- 7 chocolate_008.jpg	Aug 17, 2022 at 10:53 AM			ANOMALY	Select	2.8
			Aug 17 2022 at 10-52		100	C	manusan	10.22
	In 10282a8e-act Deadadabd86)f-47c8-9c60- f chocolate_007.jpg	A0g 17, 2022 at 10:35 AM			ANOMALY	Select	~ •



- Make sure all training anomaly images are marked with a check mark.
- Next, register test images to be used for AI performance verification. Press the "Normal Test image" button.

1	ADFI									HOME
		(At least	1 data)		Normal: 0, 4	Anomaly: 0				
	Project	Al Model	Status		No Al mode	exists				
	Billing		AI MODE	L INSPECTION RANGE	SETTING AI MODE	EL SETTING	TEST	API		
	API		Normal Training image	▲ Anomalous Training	image 🛆 Normal T	est image	🗅 Anomalous	Test image	Delete AL	L Data
	Sample Dataset	Image	List		👄 Create	Al Model	🔋 Delete Al N	lodel 🖶 Re	-training 🖷	• Test
	Operation Manual	Img	ID	Name	Created \downarrow	ForTraining	ForTest	Label	cellSelected	Actions
			b470798e-ebc3-475f-b0f5- 282a7ff0cd3e	chocolate_010.jpg	Aug 17, 2022 at 10:53 AM			ANOMALY	0	21
			a719a5af-a5c7-4d76-ac1f- fcc15ef877ee	chocolate_009.jpg	Aug 17, 2022 at 10:53 AM			ANOMALY	0	/ =
			eed53b17-4a96-407e-b166- 2af5c3d44d37	chocolate_008.jpg	Aug 17, 2022 at 10:53 AM	7		ANOMALY	0	21
			10282a8e-ac0f-47c8-9c60- 0eadadabd86f	chocolate_007.jpg	Aug 17, 2022 at 10:53 AM			ANOMALY	0	Z II.
			c0e3843c-6b50-4b0e-b023- fece2b8a9a18	chocolate_006.jpg	Aug 17, 2022 at 10:53 AM			ANOMALY	0	× 1
			be95ebd5-c844-4b81-b8b9- 18b2c66f5316	chocolate_005.jpg	Aug 17, 2022 at 10:53 AM			ANOMALY	0	/=
			e7d4efa9-6b37-455e-a79a- f7dbfa2ab9e0	chocolate_004.jpg	Aug 17, 2022 at 10:53 AM	Y		ANOMALY	0	Z II.
			ff48188d-da66-4755-a783- c9ad26c8cc0d	chocolate_003.jpg	Aug 17, 2022 at 10:53 AM			ANOMALY	0	/=
			457d3f4a-41f3-43dd-91bc- 1ee1221034fc	chocolate_002.jpg	Aug 17, 2022 at 10:53 AM			ANOMALY	0	/=
			bb73e771-5b9d-406c-b11a- 2c233611e653	chocolate_001.jpg	Aug 17, 2022 at 10:53 AM	$\mathbf{\mathbf{y}}$		ANOMALY	0	Z II.
							Rows per page:	10 👻	1-10 of 60	< >



- Open the good folder (Coffee_beans -> test -> good) inside the test folder of the sample image dataset.
- Select all the images in the good folder and press the "Open" button.
 - In Windows, you can select all at once with the "Ctrl" button + "A" button.





- After the upload of the normal image is completed, the normal image for performance verification is added to the image list.
- Finally, register anomalous test images to be used for AI performance verification. Press the "Anomalous Test image" button.





- Open the candy folder (Coffee_beans -> test -> candy) in the test folder of the sample image dataset.
 - This time, candy is not included in the training anomalous images, but ADFI can detect anomalies that have not been trained.
- Select all the images in the candy folder and press the "Open" button.





- By uploading the anomalous images of candy, the anomalous images for performance verification ware added to the image list.
- In addition, add an anomalous images (chocolate) for performance verification. Press the "Anomalous Test image" button.

=	ADFI										HOME	YOURUSERNAM
•	Project Billing API	Sample Ir	nage				S. Here					
Ŀ	Sample Dataset	Plan				Free (Remainin	g 14 days)					
0	Operation Manual	Payer)									
		API Call S	itatus			Not available (F	Free API avai	able: 100) 🎄	ô			
		Training ((At least))ata 20 normal data and 5 anomalous data)			Total: 60 Normal: 50, An	omaly: 10					
		Test Data (At least	1 data)			Total: 25 Normal: 20, An	omaly: 5					
		Al Model	Status			No Al model ex	ists					
			AI MODEL	INSPECTION RANGE	SETTING	AI MODEL :	SETTING	TEST	API			
			• Normal Training image	Anomalous Training	image 🕻	Normal Test	t image	🛆 Anomalous	Test image	Delete ALL	Data	
		Image	List			de Create A	I Model	🔋 Delete Al N	lodel dp Re-	training എ	Test	
		Img	ID	Name	Created \downarrow		ForTraining	ForTest	Label	cellSelected	Actions	
			9bb791fd-f33f-48f8-8ada- c44ac7505084	NG_candy_005.jpg	Aug 17, 20 AM	22 at 11:32			ANOMALY		/ =	
			bcb1c8ed-91a6-4687-b92d- b3fd24e86e22	NG_candy_004.jpg	Aug 17, 20 AM	22 at 11:32			ANOMALY		Z II.	
			8cd4108b-5bc2-463b-b31c- cd4bb8c6580b	NG_candy_003.jpg	Aug 17, 20 AM	22 ət 11:32			ANOMALY		/=	
			6e44e69f-b187-4267-90c9- a1eb3bb0de15	NG_candy_002.jpg	Aug 17, 20 AM	22 at 11:32			ANOMALY		/ =	
			66a08e0e-708a-465a-85b0- 96a61e9ed168	NG_candy_001.jpg	Aug 17, 20 AM	22 at 11:32			ANOMALY		Z II.	
		-	08efd1cf-5a0c-4abf-8136-	OK anad 020 ins	Aug 17, 20	22 at 11:26				_		

- **ADFI**
- Open the chocolate folder (Coffee_beans -> test -> chocolate) in the test folder of the sample image dataset.
- Select all the images in the chocolate folder and press the "Open" button.





- By uploading the anomalous images of chocolate, the anomlous images for performance verification were added to the image list.
- Check the number of "Training Data" and "Test Data". These indicate the number of images registered for AI training and performance verification. The dataset is now ready.





3. Creation of an image anomaly detection Al

3. Creation of an image anomaly detection AI



- Once the dataset is ready, create an image anomaly detection AI.
- Press "Create AI Model" in the center. Training begins.

=	ADFI									номе
9 11 0	Project Billing API	Sample I	Image							
ŀ	Sample Dataset	Plan			Free (Remai	ning 14 days)				
0	Operation Manual	Payer 🦪	٥							
		API Call	Status		Not availabl	e (Free API avail	able: 100) 🄅	ê		
		Training (At least	Data 20 normal data and 5 anomalous data)		Total: 60 Normal: 50	Anomaly: 10				
		Test Dat	a 1 data)		Total: 40	Anomaly: 20				
		Al Mode	(Status		No Al mode	exists				
			AI MODEL	INSPECTION PANGE		I SETTING	TEST	API		
			Normal Training image	Anomalous Training in	ane 🛆 Normal T	est image	Anomalou	s Test image	Delete ALL	Data
		Image	List		de Create	Al Model	🗑 Delete Al	Model de Re	-training ap	Test
		Img	ID	Name	Created 4	ForTraining	ForTest	Label	cellSelected	Actions
			0200003a-0e62-45fb-83ab- 145ba63109a4	NG_chocolate_015.jpg	Aug 17, 2022 at 1:23 PM			ANDMALY		/ =
			ec5ec3b6-66ee-4c24-bd83- c2796b64001a	NG_chocolate_014.jpg	Aug 17, 2022 at 1:23 PM			ANOMALY		Z II.
			72f768c2-ff8b-4916-959d- b4f4f011c54a	NG_chocolate_013.jpg	Aug 17, 2022 at 1:23 PM			ANOMALY		/ =
			43589323-b11e-4eef-8a2e- bbb246efe24e	NG_chocolate_012.jpg	Aug 17, 2022 at 1:23 PM			ANOMALY		/ =
			7c4a9c49-8fef-42f1-8f9d- 5ec00508f454	NG_chocolate_011.jpg	Aug 17, 2022 at 1:23 PM			ANOMALY		Z II.
		-	e6925ca2-bc2c-49fe-b67c-	NC sharelets 010 ins	Aug 17, 2022 at 1:23				_	

3. Creation of an image anomaly detection Al



- When AI learning starts, AI Model Status will show "Learning in progress (Preparing to train)".
- After a while, the learning progress will be displayed like "Learning in progress (6. 6%)".
- Wait for the AI to finish training.
 - Al learning time varies depending on the number of training images. Learning is usually completed in about 15 to 60 minutes.
 - If by any chance the progress has stopped after a few hours, please press "Delete AI Model" and then "Create AI Model" again.

=	ADFI											номе	YOURUSERNAM	
•	Project		< Back to Datas	o Project Detail Page et Detail										
6	API		Dataset	Name	Sample Datase	t								
٥	Sample Dataset		Dataset	D	ee0f3b37-4878	-44b6-b05	9-22798804387	73						
0	Operation Manual		Owner N	lame	YourUserName									
			Sample I	Image		sitter.								
			Plan		Free (Remainin	g 14 days)								
			Payer (?	0										
			API Call	Status	Not available (F	ree API av	ailable: 100) 🚦	¢ ô						
			Training (At least	Data 20 normal data and 5 anomalous data)	Total: 60 Normal: 50, An	omaly: 10								
			Test Dat	a 1 data)	Total: 40 Normal: 20, And	omaly: 20								
			Al Model	l Status	Learning in pro	gress (Pre	paring to train)	ur clease	delete the Al mod	al and recreate n	ew.00e			
				AI MODEL	INSPECTION RANGE S	ETTING	AI MODEL	. SETTING	TEST	API				
				Normal Training image	Anomalous Training Im	age 🖌	Normal Te	st image	Anomalous	s Test image	Delete ALI	. Data		
			Image	List			🖶 Create.	Al Model	📋 Delete Al M	Model 🔶 R	e-training 🖷	Test		
			Img	ID	Name	Created	Ŷ	ForTraining	ForTest	Label	cellSelected	Actions		
				0200003a-0e62-45fb-83ab- 145ba63109a4	NG_chocolate_015.jpg	Aug 17, PM	2022 at 1:23		y	ANOMALY		× 1		
				ec5ec3b6-66ee-4c24-bd83- c2796b64001a	NG_chocolate_014.jpg	Aug 17, PM	2022 at 1:23			ANOMALY		/ 1		
Соруг	ght © 2022 AI ROBOTICS L	TD. All rights reserved.												l

=	ADFI		HOME YOUR	USERNAME 🔻
	Project	-		
	Billing	Sample Image		
٢	API			
+	Sample Dataset	Plan Free (Rem	aining 14 days)	
0	Operation Manual	Payer ⑦		
		API Call Status Not availa	ole (Free API available: 100) 🔹 🔒	
		Training Data Total: 60 (At least 20 normal data and 5 anomalous data) Normal: 5	, Anomaly: 10	
		Test Data Total: 40 (At least 1 data) Normal: 2	Anomaly: 20	
		Al Model Status	progress (6.6%)	ıe.
		AI MODEL INSPECTION RANG	E SETTING AI MODEL SETTING TEST API	
		♠ Normal Training image ♠ Anomalous Training im	age 🚯 Normal Test image 🚯 Anomalous Test image 📋 Del	ete ALL Data
		Image List	母 Create Al Model 🔋 Delete Al Model 母 Re-training	g 🖶 Test
		Img ID Name	Created	elected Action
		©200003a-0e62-45fb-83ab- 145ba63109a4 NG_chocolate_015.jp	Aug 17, 2022 at I:23 PM	21
		005003b6 6600 4024 bd82	Aug 17, 2022 of	

3. Creation of an image anomaly detection Al



- When AI learning is completed, "AI model creation complete" is displayed in "AI Model Status".
- The image anomaly detection AI is now created.

≡	ADFI		HOME YOURUSERNAME -
9 8 8	Project Billing API	Sample Image	
3	Sample Dataset	Plan Free (Remaining 13 days)	
?	Operation Manual	Payer ⑦	
		API Call Status Available (Free API available: 100)	÷
		Training Data Total: 60 (At least 20 normal data and 5 anomalous data) Normal: 50, Anomaly: 10	
		Test Data Total: 40 (At least 1 data) Normal: 20, Anomaly: 20	
		Al Model Status Al model creation complete	
		AI MODEL INSPECTION RANGE SETTING AI MODEL SETTING TEST	API
		🛆 Normal Training image 🗳 Anomalous Training image 🗳 Normal Test image 🗳 Anomalous T	Test image 🔋 Delete ALL Data
		Image List Delete AI Model	<mark>odel</mark> 冊 Re-training 冊 Test
		Img ID Name Created J ForTraining ForTest	Label cellSelected Actions
		0200003a-0e62-45fb-83ab- 145ba63109a4 NG_chocolate_015.jpg Aug 17, 2022 at 1:23 PM I	ANOMALY
		ec5ec3b6-66ee-4c24-bd83-	
Copyri	ght © 2022 AI ROBOTICS LT	D. All rights reserved.	





- After AI creation is complete (when "AI Model Status" is "AI model creation complete"), you can use the image you just registered for test to verify the AI's performance.
- First, press the "AI MODEL SETTING" tab. Here you can change the thresholds of anomaly score or check the histogram of anomaly score for the test images.









- Click the "TEST" tab. A summary of test results at the current threshold (default threshold) is displayed.
- By pressing the "Download" button, you can download a CSV file of detailed information (a list of detection results by the AI for each image).

≡	ADFI			HOME YOURUSERNAME -
۲	Project	Test Data (At least 1 data)	Total: 40 Normal: 20, Anomaly: 20	
	Billing	Al Model Status	AI model creation complete	
	API	AI MODEL INSPECTION	RANGE SETTING AI MODEL SETTING TEST	API
•	Sample Dataset	Test Result		🖶 Test 🚯 Download
		ROC-AUC	No data	
		Number of images	40	
		Correct Answers (main)	31	
		Accuracy (main)	0.775	
		Recall (main)	1.000	
		Precision (main)	0.690	
		Correct answers (sub)	27	
		Accuracy (sub)	0.675	
		Recall (sub)	1.000	
		Precision (sub)	0.606	



- Click the "AI MODEL SETTING" tab again. Change the thresholds to any value by referring to the CSV file downloaded earlier and the histogram at the bottom. Two thresholds ("main" and "sub") can be set.
- After entering the values, press the "Save Threshold" button, and the entered values will be reflected in the thresholds.

≡ ADFI	HOME YOURUSERNAME -	How to use two thresholds	1
Project	AI MODEL INSPECTION RANGE SETTING AI MODEL SETTING TEST API		
Billing	Threshold 🖾 Save Threshold 🖾 Set Auto Threshold	High anomaly score	
API	Threshold (main)		
Operation Manual	Threshold (sub) 0.6	Anomaly	
	Histogram of the entire image	main threshold	
	30-	Not Clear	
	25	Normal	
Copyright © 2022 AI ROBOTICS	TD. All rights reserved.	Low anomaly score	4



- Click the "TEST" tab. The Test results are "No data" because the threshold has been changed.
- If you press the "TEST" button on the right side, AI verification will be executed again with the changed thresholds.

	ADFI		HOME YOURUSERNAM	IE 🔻
		(Acreast zo normal data and 5 anomalous data)	Normal, 50, Anomaly, 10	
		Test Data	Total: 40	
	Project	(At least 1 data)	Normal: 20. Anomaly: 20	
		(read r and)	rearran za, sirarran, za	
	Billing	Al Model Status	AI model creation complete	
0	API			
•		AI MODEL INSPECTION RANGES	ETTING ATMODEL SETTING TEST APT	
ŧ	Sample Dataset	Test Result	🛱 Test 🕐 Downld	oad
0	Operation Manual	restricture		0 a a
		ROC-AUC	No data	
		Number of images	No data	
		Correct Answers (main)	No data	
		Accuracy (main)	No data	
		Recall (main)	No data	
		Precision (main)	No data	
		Correct answers (sub)	No data	
		Accuracy (sub)	No data	
		Recall (sub)	No data	
		Precision (sub)	No data	
onvri				



- The test results after changing the thresholds are displayed. Especially ROC-AUC and Recall are important.
 - ROC-AUC: AI discrimination performance value (1.0 is the highest value)
 - Recall: Recall rate (1.0 means zero oversight of anomalies)
- By pressing the "Download" button on the right, you can download the CSV file of the changed thresholds.

	ADFI			HOME	TOURUSERNAME
Ŷ	Project	Test Data (At least 1 data)	Total: 40 Normal: 20, Anomaly: 20		
	Billing	Al Model Status	AI model creation complete		
	API	AI MODEL INSPECTION RANGE SI	ETTING AI MODEL SETTING TEST	API	
•	Sample Dataset Operation Manual	Test Result		÷	Test 🗅 Download
		ROC-AUC	0	.907	
		Number of images	4	10	
		Correct Answers (main)	3	4	
		Accuracy (main)	0	1.850	
		Recall (main)	1	.000	
		Precision (main)	O	1.769	
		Correct answers (sub)	3	14	
		Accuracy (sub)	0	1.850	
		Recall (sub)	1	.000	
		Precision (sub)	0	1.769	



- Show a heatmap for each image.
- In the "AI MODEL" tab, press the icon on the left side of an anomalous test image ("ForTest" is a checkmark and "Label" is "ANOMALY").

=	ADFI							номе	YOURUSEF	NAME 🔻
Ŷ	Project	AI Model Status AI model creation complete								
	Billing		AI MODEL	INSPECTION RANGE S	ETTING AI MO	DEL SETTIN	g test	API		
•	API	6	Normal Training image 🛛 🛆	Anomalous Training image	🛆 Normal Te	est image	🛆 Anomalous	Test image	📱 Delete A	LL Data
₽	Sample Dataset	Image	e List		🖶 Create	Al Model	📋 Delete Al M	odel dep Re	-training	dep Test
0	Operation Manual	Img	ID	Name	Created \downarrow	ForTraining	ForTest	Label	cellSelected	Action:
		R	0200003a-0e62-45fb-83ab- 145ba63109a4	NG_chocolate_015.jpg	Aug 17, 2022 at 1:23 PM			ANOMALY		/ 1
		ŝ	ec5ec3b6-66ee-4c24-bd83- c2796b64001a	NG_chocolate_014.jpg	Aug 17, 2022 at 1:23 PM			ANOMALY		/ 1
		2	72f768c2-ff8b-4916-959d- b4f4f011c54a	NG_chocolate_013.jpg	Aug 17, 2022 at 1:23 PM			ANOMALY		/ 1
		2	43589323-b11e-4eef-8a2e- bbb246efe24e	NG_chocolate_012.jpg	Aug 17, 2022 at 1:23 PM			ANOMALY		2.0
		2	7c4a9c49-8fef-42f1-8f9d- 5ec00508f454	NG_chocolate_011.jpg	Aug 17, 2022 at 1:23 PM			ANOMALY		/ 1
		2	e6925ca2-bc2c-49fe-b67c- b020c38e8a91	NG_chocolate_010.jpg	Aug 17, 2022 at 1:23 PM			ANOMALY		/ =
		2	08577b64-b88d-44e1-b027- be96bc328713	NG_chocolate_009.jpg	Aug 17, 2022 at 1:23 PM			ANOMALY		2.1
opyrie		EO D. All sights	2ccbd815-abe8-4b74-ba62-		Aug 17, 2022 at	-	-		-	



- A heat map inspected by the created AI is displayed.
 - The red area is the attention region. Represents the area that AI focused on when detecting it as an anomaly.
 - In the case of a normal image, there are no anomlaous areas, so the attention area spreads thinly over the entire image without being concentrated.
- After confirming, click "CLOSE" at the bottom right.



Anomaly



Normal



45



5. Supplementary information

Use of the AI from your systems



- ADFI provides APIs so that created AI can be used from your systems.
- Click the "API" tab. Sample codes for API calls are displayed at the bottom.
 - In the case of the free plan, there is an upper limit on the number of times API can be used.

≡	ADFI		HOME YOURUSERNAME -					
۲	Project	AI MODEL	L INSPECTION RANGE SETTING AI MODEL SETTING TEST					
=	Billing API Sample Dataset Operation Manual	API						
		API Key	68a9310bd8fd4f7aa943ca8979464c71					
•		AI Model ID	ce9a4343-40d4-4ad3-93fd-56e9d21f6904 2					
		Model Type						
		API Detail	Detail					
		curl "https://us.adfi.karakurai.com/API/ap/api/apidata/" -F apikey=68a9310bd8fd4f7aa943ca8979464c71 -F aimodel_id=ce9a4343-40d4-4ad3-93fd- 56e9d21f6904 -F model_type=2 -F image_data=@ <image file="" path=""/>						
		Example API call using Py import json import requests from PIL import Image # pip install P from io import BytesIO # Set your image file path filename = 'your_image_file_path.png apikey = '68a9310bd8fd4f7aa943cae	ython 'illow g" 8979464c71* 13145560d216004*					
Copyright © 2022 AI ROBOTICS LTD. All rights reserved.								

Change to paid plan



- In free plan, a dataset is automatically deleted at the end of the free trial period.
 - "Remaining days" is the remaining number of days for free trial. The number of days is set for each dataset.
- When using the created AI from your system, press "Free" in the "Plan" to move to the plan change page. Please change the dataset to a paid plan there. (Credit card registration is required.)

≡	ADFI			ном	E YOURUSERNAME 🔻				
•	Project Billing	<< Back to Project Detail Page Dataset Detail							
ø	API	Dataset Name		Sample Dataset					
+	Sample Dataset	Dataset ID		ee0f3b37-4878-44b6-b059-227988043873					
0	Operation Manual	Owner Name		YourUserName					
		Sample Image							
		Plan		Free (Remaining 13 days)					
		Payer 🕐							
		API Call Status		Available (Free API available: 100) 🎄 🔒					
		Training Data (At least 20 normal data and 5 anomalous dat	a)	Total: 60 Normal: 50, Anomaly: 10					
		Test Data (At least 1 data)		Total: 40 Normal: 20, Anomaly: 20					
		Al Model Status		AI model creation complete					
		AI MODEL	INSPECTION RANGE SETTING	AI MODEL SETTING TEST API					
Copyright © 2022 AI ROBOTICS LTD. All rights reserved.									

Operation manual



- For details on ADFI operation and how to use the created AI from your systems, please refer to the operation manual.
- Operation manual URL: <u>https://adfi.jp/manual/</u>